

Attach the inflator valve to the female end of a length(s) of 2 ½ inch hose, then attach the cap to the male end. Be sure to tighten connections to prevent air leaks.



There are two methods for inflating the hose, (above) the bottle mounted air bag inflator can be connected to any SCBA bottle with the double female air hose. Both are located in the "regulator box" located in the rear officer side compartment on Rescue 1.

- Connect the regulator to the bottle
- Connect the double female air hose to the regulator
- Connect the other end of the air hose to the fire hose inflator valve
- Open the SCBA bottle
- Open the shut off valve on the end of the air hose
- SLOWLEY open the fire hose inflator until the hose becomes fully charged with air
- Use caution to not over pressurize the hose
- Once fully inflated, the fire hose inflator valve may be closed and opened as necessary to maintain proper inflation in the hose

