

Training for Essex County

Name:

Date:

SCBA- 12: SCBA Use

Wearing full PPE, prep SCBA

1. Check cylinder gauge for "full" indication
2. Don SCBA using overhead method, coat method, or from seated position
3. Don face piece
4. Check seal
5. Attach regulator to face piece
6. Open cylinder valve
7. Observe Vibra-alert, HUD, remote pressure gauge, and Pak-Alert. Inhale Sharply.
8. Don remaining PPE: Helmet, hood and gloves
9. Stand with arms out for inspection. Exposed skin, twisted straps etc.
10. Remain still to allow Pak-Alert to enter pre-alert, observe control console.
11. Reset from pre-alert by either moving hips or press and hold the yellow reset button
12. Remain still to allow Pak-Alert to enter full alarm.
13. Reset from full alarm by pressing the yellow button twice
14. Depress red button to activate Pak-Alert manually
15. Reset from full alarm by pressing yellow reset button twice
16. Fully close cylinder valve
17. Breathe normally, observe HUD and remote gauge
18. Observe end of service alarm, hold breath momentarily and make certain Vibra-alert and HUD both actuate
19. Resume breathing until air stops flowing from regulator
20. Inhale and hold breath drawing face piece slightly to face with no leakage
21. Doff regulator
22. Doff helmet, hood and gloves
23. Doff face piece
24. Turn off Pak-Alert
25. Doff SCBA

Signature of Evaluator _____